

ECONOTRIM BUTTBUSTER



1. It is recommended that all perimeter holes are fired with the same detonator



2. Insert the detonator into the capwell that is fitted to the flared end (primer end) of the coil



3. Ensure the detonator is fully inserted into the capwell



4. Gently pull the detonator signal tube around and press it into the signal tube retention clasp



5. Break open the coil tapes and unroll the coil

6. Insert the explosive charge into the borehole primer end first. Make sure that the explosive charge is pushed all the way to the butt of the borehole
7. No primer or stemming cartridge is required. Tamping is not recommended
8. After connecting the signal tube J hook onto the firing line, signal tube tails should be neatly coiled