

EZISPLIT

RECOMMENDATION FOR USE

1. Charge up crew to first unpack the explosive coils from the case



3. Connect all the male and female couplings while the coils are on the ground making sure that the LokTite mechanism is properly engaged



5. Attach the EZIStarter to the female end of the last coil



7. Firmly hold the EZIStarter's detonating cord while lowering the charge into the borehole



2. Lay the correct amount of coils required to charge the hole on the ground, at right angles to the borehole



4. Connect the EZISinker to the leading male end



6. Feed the EZISinker end of the joined coils down the hole



8. Once the required charge height is achieved in the hole, tie the EZIStarter's detonating cord onto the trunk line